

Rolling Screen - Annual Maintenance

Dirt building around the mesh loops can create friction and potential wear, which will effect the ease of operation of the screen. A simple, annual procedure will avoid this.

1. Important! Open the window first! (This is to prevent getting lubricant on the glass.)
2. Pull down the screen.
3. Use a compressed air can (typical for computer cleaning) or vacuum on the channels top to bottom (both sides) to remove any dust build-up.



4. Use a silicon based lubricant such as Jig-a-loo (http://www.jigaloo.com/ca/e_home.php) with the tube inserted into the channel and gently spray a small amount, top to bottom. Note that this lubricant has no oils, grease, wax or detergent.)

